



AEGION®



Stronger. Safer. Infrastructure.®



iPlus Infusion® Installation

How iPlus Infusion® Is Installed

1. The iPlus Infusion® tubes are *wet out* using a controlled resin impregnation system that fully saturates the tube with thermosetting resin.
2. The resin-saturated tube is pulled into a damaged pipe.
3. Air is used to inflate the tube and then steam cures the resin to form a *tight-fitting, jointless* and corrosion-resistant replacement pipe.
4. Service laterals are restored internally with robotically controlled cutting devices.
5. Rehabilitated pipes are inspected by closed-circuit TV.